



EMP Code	Product Code	Name	Description
----------	--------------	------	-------------

<b>CONTACT</b>			
B02-39-223	MCB-01	CONTACT	CONTACT 1 X NC
B02-39-022	800E-2X01	CONTACT	CONTACT 1xNC
B02-39-224	MCB-10	CONTACT	CONTACT 1xNO
B02-39-160	KCB-11	CONTACT	CONTACT 1xNO/NC
B02-39-159	KCB-02	CONTACT	CONTACT 2xNC
B02-39-264	MCB-02	CONTACT	CONTACT 2xNC
B02-39-161	KCB-20	CONTACT	CONTACT 2XNO
B02-39-276	ZB4BZ103	CONTACT	CONTACT 2xNO
B02-39-207	ZBE101	CONTACT AUXILIARY	CONTACT AUXILIARY 1xNO
B02-39-171	LADN10	CONTACT AUXILIARY	CONTACT AUXILIARY FRONT MOUNTED
B02-39-172	LADN11	CONTACT AUXILIARY	CONTACT AUXILIARY FRONT MOUNTED
B02-39-006	3RH1921-1LA20	CONTACT AUXILIARY	CONTACT AUXILIARY 2XNO
B02-39-007	3RV1901-1B	CONTACT AUXILIARY	CONTACT AUXILIARY 2xNO SIDE MOUNT
B02-39-008	3RV1901-1E	CONTACT AUXILIARY	CONTACT AUXILIARY 1XNO/NC FRONT MOUNT
B02-39-023	800E-2X10	CONTACT BLOC	CONTACT BLOC 1xNO
B02-39-025	800E-3X01	CONTACT BLOC	CONTACT BLOCK 1xNC
B02-39-039	9001KA3	CONTACT BLOC	CONTACT BLOCK 1XNC
B02-39-063	CBK-CB01	CONTACT BLOC	CONTACT BLOCK 1xNC
B02-39-174	M22-KC01	CONTACT BLOC	CONTACT BLOCK 1xNC
B02-39-206	ZB4BZ102	CONTACT BLOC	CONTACT BLOCK 1XNC
B02-39-038	9001KA2	CONTACT BLOC	CONTACT BLOCK 1xNO
B02-39-064	CBK-CB10	CONTACT BLOC	CONTACT BLOCK 1xNO
B02-39-205	ZB4BZ101	CONTACT BLOC	CONTACT BLOCK 1xNO
B02-39-005	MBC-02	CONTACT BLOC	CONTACT BLOCK 2XNC
B02-39-010	3SB3400-0E	CONTACT BLOC	CONTACT BLOCK 2XNC
B02-39-009	3SB3400-0C	CONTACT BLOC	CONTACT BLOCK NC

# BUTTONS AND CONTACTS

B02-39-012	3SB3400-OB	CONTACT BLOC	CONTACT BLOCK NO
B02-39-026	800E-3X10	CONTACT BLOC	CONTACT BLOCK NO
B02-39-263	BCLF10	CONTACT BLOC	CONTACT BLOCK NO
B02-39-037	9001KA1	CONTACT BLOC	CONTACT BLOCK NO/NC
B02-39-154	KA70-1002	CONTACT BOX	CONTACT BOX
B02-39-225	MCB-11	CONTACT DOUBLE	CONTACT DOUBLE 1xNO 1xNC FOR PUSH BUTTON
B02-39-004	3RA1913-2A		CONTACTOR REVERSING ASSY KIT

<b>HOLDER</b>			
B02-39-069	CBK-H5	HOLDER	HOLDER 5 BLOCK
B02-39-226	MCBH5-00	HOLDER	HOLDER FOR FIVE BLOCKS
B02-39-178	MCBH-00	HOLDER	HOLDER FOR THREE BLOCKS
B02-39-180	MLB-1	HOLDER	HOLDER LAMP MAX. 2WATTS USE WITH B02-39-209
B02-39-056	92N4088		KNOB ALUMINUM

<b>LAMP</b>			
B02-39-138	CPP400MAAM3C-T	LAMP	LAMP
B02-39-018	43828-MVR400/U	LAMP	LAMP MULTI VAPOR BALLAST M59
B02-39-149	E26S11	LAMP	LAMP 120V
B02-39-084	CBK-LMF	LAMP	LAMP BLOCK FOR FRONT MOUNTING

<b>BULB</b>			
B02-39-209	5911086-15	BULB	LAMP BULB 120V AC/DC
B02-39-141	DLICE130	BULB	LAMP BULB 130V
B02-39-021	5911086-13	BULB	LAMP BULB 24V AC/DC
B02-39-279	DL1BLG	BULB	LAMP BULB FOR STACK LIGHT
B02-39-002	2550101002	BULB	LAMP BULBS 24V
B02-39-150	E26S9	BULB	LAMP INCANDESCENT 24V
B02-39-201	ZB4BV6	BULB	LAMP MODULE 120V
B02-39-140	DL1BEB	BULB	BULB FOR STACK LIGHT 24VAC/DC
B02-39-166	KLB1 USE B02-39-280	BULB	BULB FOR STACKLIGHT 115V 5W
B02-39-280	KA4-1118	BULB	BULB FOR STACKLIGHT 115V 5W
B02-39-240	KLB2	BULB	BULB FOR STACKLIGHT 230V 5W
B02-39-167	KA4-1028	BULB	BULB FOR STACKLIGHT 24V 5W
B02-39-081	CBK-LBDG	BULB	BULB GREEN 24V
B02-39-011	3SB3400-1A	BULB HOLDER	BULB HOLDER
B02-39-079	CBK-LBD1W	BULB	BULB LIGHT 120V LED
B02-39-082	CBK-LBDR	BULB	BULB RED 24V
B02-39-185	SP-105	BULB	LIGHT BULB 130V

# BUTTONS AND CONTACTS

B02-39-183	Q100T3CL130	BULB	LIGHT BULB 3 1/8"130V100W
B02-39-182	MVR400/U GE-LAMP	BULB	LIGHT BULB ED37 MOG CLEAR M59 4000K
B02-39-153	HR400DX33	BULB	LIGHT BULB EXTERIOR LAMPS 400W 120V MERC.
B02-39-179	MH-400U	BULB	LIGHT BULB METAL HALIDE

<b>LED</b>			
B02-39-256	KA2-2222	LED	LED 220V AC/DC GREEN
B02-39-080	CBK-LBD8W	LED	LED 24 VAC/DC WHITE
B02-39-281	KA2-2024	LED	LED 24V AC/DC BLUE
B02-39-241	KA2-2022	LED	LED 24V AC/DC GREEN
B02-39-282	KA2-2025	LED	LED 24V AC/DC GREEN
B02-39-242	KA2-2021	LED	LED 24V AC/DC RED
B02-39-311	3072T1-WHITE	LED	LED LIGHTS 10-28VDC WHITE
B02-39-208	ZBVG1	LED	LED MODULE WHITE 120VAC
B02-39-168	KSB-307R	LED	LED ROTATING LIGHT

<b>LENS</b>			
B02-39-144	E26B9	LENS	LENS AMBER
B02-39-143	E26B3	LENS	LENS GREEN
B02-39-142	E26B2	LENS	LENS RED

<b>MUSHROOM PUSH BUTTON</b>			
B02-39-013	3SB3500-1HA20	MUSHROOM PUSH BUTTON	MUSHROOM "E-STOP
B02-39-068	CBK-ESP4R	MUSHROOM PUSH BUTTON	MUSHROOM 22MM PUSH-PULL
B02-39-029	800ES-MT4	MUSHROOM PUSH BUTTON	MUSHROOM PUSH BUTTON PUSH-PULL
B02-39-053	9001KR9R	MUSHROOM PUSH BUTTON	MUSHROOM PUSHBUTTON ILLUMINATED
B02-39-200	ZB4BS54	MUSHROOM PUSH BUTTON	MUSHROOM PUSHBUTTON PUSH-TURN
B02-39-237	MPMP3-11R	MUSHROOM PUSH BUTTON	MUSHROOM PUSH-PULL, ILLUM RED, 40MM
B02-39-236	MPMP3-10R	MUSHROOM PUSH BUTTON	MUSHROOM PUSH-PULL, NON-IL RED, 40MM
B02-39-067	CBK-ESP4IR	MUSHROOM PUSH BUTTON	EMERGENCY STOP MUSHROOM ILL.PUSH-PULL
B02-39-176	M22-PV	MUSHROOM PUSH BUTTON	EMERGENCY STOP PUSH PULL

# BUTTONS AND CONTACTS

NAMEPLATE			
B02-39-265	9001KN200	NAMEPLATE	NAMEPLATE BLANK
B02-39-034	800T-X559	NAMEPLATE	NAMEPLATE "BLANK" 30MM
B02-39-035	800T-X618	NAMEPLATE	NAMEPLATE "PUSH TO STOP"
B02-39-043	9001KN202	NAMEPLATE	NAMEPLATE (40 X 42MM) STOP
B02-39-042	9001KN201	NAMEPLATE	NAMEPLATE (40 X 43MM) START
B02-39-046	9001KN246	NAMEPLATE	NAMEPLATE (OPEN-CLOSE)
B02-39-036	800T-X646EM	NAMEPLATE	NAMEPLATE 30MM P-B ROUND YELLOW
B02-39-258		NAMEPLATE	ALUMINUM 22MM 0-10
B02-39-307	CBK-NPF20	NAMEPLATE	ALUMINUM 22MM ARRÊT
B02-39-300	CBK-NPF3	NAMEPLATE	ALUMINUM 22MM ARRÊT D'URGENCE
B02-39-269		NAMEPLATE	ALUMINUM 22MM AUTO / MANUAL
B02-39-104	CBK-CDS-16	NAMEPLATE	ALUMINUM 22MM BLADE READY
B02-39-108	CBK-NPE28	NAMEPLATE	ALUMINUM 22MM BLANK
B02-39-116	CBK-CDS-1	NAMEPLATE	ALUMINUM 22MM BLOWER START
B02-39-117	CBK-CDS-2	NAMEPLATE	ALUMINUM 22MM BLOWER STOP
B02-39-099	CBK-NPE1	NAMEPLATE	ALUMINUM 22MM CLOSE
B02-39-123	CBK-CDS-21	NAMEPLATE	ALUMINUM 22MM CONSTANT CUT / MAN. CUT
B02-39-110	CBK-CDS-11	NAMEPLATE	ALUMINUM 22MM COOLING
B02-39-308	CBK-NPF19	NAMEPLATE	ALUMINUM 22MM DÉPART
B02-39-271	CBK-NPE2	NAMEPLATE	ALUMINUM 22MM DOWN
B02-39-112	CBK-CDS-12	NAMEPLATE	ALUMINUM 22MM DOWN/UP
B02-39-124	CBK-CDS-19	NAMEPLATE	ALUMINUM 22MM EMERGENCY STOP
B02-39-250	CBK-NPE34	NAMEPLATE	ALUMINUM 22MM FAULT
B02-39-132	CBK-NPE5	NAMEPLATE	ALUMINUM 22MM FORWARD
B02-39-127	CBK-NPE32A	NAMEPLATE	ALUMINUM 22MM FWD / REV
B02-39-257	CBK-NPE22A	NAMEPLATE	ALUMINUM 22MM HAND / AUTO
B02-39-302	CBK-NPF24	NAMEPLATE	ALUMINUM 22MM HORS - EN
B02-39-131	CBK-NPE40	NAMEPLATE	ALUMINUM 22MM JOG
B02-39-266		NAMEPLATE	ALUMINUM 22MM JOG REVERSE
B02-39-115	CBK-CDS-22	NAMEPLATE	ALUMINUM 22MM KEYPAD / MANUAL
B02-39-251	CBK-NPE36	NAMEPLATE	ALUMINUM 22MM LOCAL / AUTO
B02-39-272		NAMEPLATE	ALUMINUM 22MM MAN- PLC-AUTO
B02-39-270		NAMEPLATE	ALUMINUM 22MM MAN. CUT / CONST. CUT
B02-39-113	CBK-NPE39A	NAMEPLATE	ALUMINUM 22MM MAN. DIGI-LOCK
B02-39-130	CBK-NPE38A	NAMEPLATE	ALUMINUM 22MM MANUAL CUT
B02-39-292	CBK-CDS-XX	NAMEPLATE	ALUMINUM 22MM MANUAL/KEYPAD
B02-39-114	CBK-CDS-23	NAMEPLATE	ALUMINUM 22MM MASTER / FOLLOWER

# BUTTONS AND CONTACTS

B02-39-267	CBK-CDS-17	NAMEPLATE	ALUMINUM 22MM NORMAL CYCLE/HOME RESET
B02-39-107	CBK-NPE24A	NAMEPLATE	ALUMINUM 22MM OFF / ON 90 DEG
B02-39-106	CBK-NPE24	NAMEPLATE	ALUMINUM 22MM OFF / ON 45DEG
B02-39-268	CBK-CDS-18	NAMEPLATE	ALUMINUM 22MM OFF-DRAIN-REFILL
B02-39-100	CBK-NPE12	NAMEPLATE	ALUMINUM 22MM OPEN
B02-39-129	CBK-NPE37A	NAMEPLATE	ALUMINUM 22MM OPEN / CLOSE
B02-39-109	CBK-CDS-20	NAMEPLATE	ALUMINUM 22MM POWER ON
B02-39-310	CBK-NPF11	NAMEPLATE	ALUMINUM 22MM POWER ON
B02-39-299	CBK-NPF14	NAMEPLATE	ALUMINUM 22MM RÉARMEMENT
B02-39-101	CBK-NPE14	NAMEPLATE	ALUMINUM 22MM RESET
B02-39-126	CBK-CDS-05	NAMEPLATE	ALUMINUM 22MM REV / FWD
B02-39-248	CBK-NPE15	NAMEPLATE	ALUMINUM 22MM REVERSE
B02-39-102	CBK-NPE16	NAMEPLATE	ALUMINUM 22MM RUN
B02-39-118	CBK-CDS-3	NAMEPLATE	ALUMINUM 22MM SAW START
B02-39-119	CBK-CDS-4	NAMEPLATE	ALUMINUM 22MM SAW STOP
B02-39-103	CBK-NPE19	NAMEPLATE	ALUMINUM 22MM START
B02-39-105	CBK-NPE20	NAMEPLATE	ALUMINUM 22MM STOP
B02-39-120	CBK-CDS-8	NAMEPLATE	ALUMINUM 22MM SYSTEM RESET
B02-39-121	CBK-CDS-6	NAMEPLATE	ALUMINUM 22MM SYSTEM START
B02-39-122	CBK-CDS-7	NAMEPLATE	ALUMINUM 22MM SYSTEM STOP
B02-39-111	CBK-CDS-10	NAMEPLATE	ALUMINUM 22MM TANK
B02-39-128	CBK-CDS-13	NAMEPLATE	ALUMINUM 22MM UP / DOWN
B02-39-017	3SB3921-OAD	NAMEPLATE	EMERGENCY STOP
B02-39-047	9001KN8330	NAMEPLATE	NAMEPLATE EMERGENCY STOP
B02-39-249	CBK	NAMEPLATE	KEYPAD MANUAL
B02-39-044	9001KN236	NAMEPLATE	MOTOR RUN
B02-39-045	9001KN237	NAMEPLATE	MOTOR STOP
B02-39-041	9001KN379	NAMEPLATE	PULL TO START
B02-39-247	SK615546-4	NAMEPLATE	ROUND YELLOW ARRET D'URGENCE
B02-39-125	SK615546-2	NAMEPLATE	ROUND YELLOW EMERGENCY STOP

<b>PERMANENT LIGHT</b>			
B02-39-163	KL70-401L	PERMANENT LIGHT	12-240VAC/DC BLUE
B02-39-162	KL70-401G	PERMANENT LIGHT	12-240VAC/DC GREEN
B02-39-189	XVBC33	PERMANENT LIGHT	12-240VAC/DC GREEN
B02-39-164	KL70-401R	PERMANENT LIGHT	12-240VAC/DC RED
B02-39-190	XVBC34	PERMANENT LIGHT	12-240VAC/DC RED
B02-39-165	KL70-401Y	PERMANENT LIGHT	12-240VAC/DC YELLOW

<b>PILOT LIGHT</b>			
B02-39-227	ML1-100G	PILOT LIGHT	22MM GREEN
B02-39-228	ML1-100R	PILOT LIGHT	22MM RED
B02-39-238	ML1-100Y	PILOT LIGHT	22MM YELLOW
B02-39-048	9001KP35G31	PILOT LIGHT	30.5MM GREEN
B02-39-049	9001KP35R31	PILOT LIGHT	30.5MM RED
B02-39-309	800EM-PL5	PILOT LIGHT	AMBRE 22MM
B02-39-074	CBK-KLFC	PILOT LIGHT	CLEAR
B02-39-016	3SB3501-6BA40	PILOT LIGHT	GREEN
B02-39-304	800EM-PL3	PILOT LIGHT	GREEN 22MM
B02-39-070	CBK-KLF1G	PILOT LIGHT	GREEN C/W BUL
B02-39-077	CBK-LB1	PILOT LIGHT LAMP BULB	130V
B02-39-078	CBK-LB24	PILOT LIGHT LAMP BULB	24V
B02-39-083	CBK-LBN2	PILOT LIGHT	NEON 240V
B02-39-071	CBK-KLF1R	PILOT LIGHT	RED 22MM
B02-39-072	CBK-KLF1W	PILOT LIGHT	WHITE
B02-39-073	CBK-KLF1Y	PILOT LIGHT	YELLOW
B02-39-058	CBG-KLF1Y	PILOT LIGHT	YLW, 120V DIRECT, INCAN 30MM MTG
B02-39-177	M22-XZKGB99		PLATE

<b>PUSH BUTTON</b>			
B02-39-244	MPD15-11C	PUSH BUTTON	ILLUM, DOUBLE START-STOP
B02-39-233	MP3-31L	PUSH BUTTON	ILLUM, EXTENDED BLUE
B02-39-235	MP3-30R	PUSH BUTTON	NON-IL, EXTEND MOMENTARY, RED
B02-39-230	MP1-30G	PUSH BUTTON	NON-ILLUM, FLUSH GREEN, 22MM
B02-39-229	MP1-30B	PUSH BUTTON	NON-ILLUM, FLUSH MOMENTARY, BLACK, 22MM
B02-39-231	MP1-30L	PUSH BUTTON	NON-ILLUM, FLUSH MOMENTARY, BLUE, 22MM
B02-39-075	CBK-KPM-40B	PUSH BUTTON	PUSH BUTTON
B02-39-234	MP3-31R	PUSH BUTTON	RED
B02-39-050	9001KR1BH5	PUSH BUTTON	BLACK
B02-39-096	CBK-MPL	PUSH BUTTON	BLUE
B02-39-028	800EP-LU2C23	PUSH BUTTON	DOUBLE MOMENTARY
B02-39-094	CBK-MPIFG	PUSH BUTTON	G ILLUMINATED
B02-39-015	3SB3501-0AA41	PUSH BUTTON	GREEN
B02-39-019	52AAGL	PUSH BUTTON	GREEN
B02-39-051	9001KR1GH5	PUSH BUTTON	GREEN
B02-39-306	800EM-LF3	PUSH BUTTON	GREEN EXTEND 22MM, ILLUMINATED
B02-39-062	CBK-2P1C	PUSH BUTTON	ILL TWO BUTTON

# BUTTONS AND CONTACTS

B02-39-093	CBK-MPIF8L	PUSH BUTTON	ILL. BLUE
B02-39-297	800EM-LF9	PUSH BUTTON	ILLUM. 22MM WITHOUT LENS
B02-39-243	MP3-31R	PUSH BUTTON	ILLUMINATED MOMENTARY, EXTENDED RED
B02-39-097	CBK-MPPEB	PUSH BUTTON	MAINT. BLACK
B02-39-195	ZB4BA2	PUSH BUTTON	MOMENTARY BLACK
B02-39-196	ZB4BA36	PUSH BUTTON	MOMENTARY GREEN
B02-39-204	ZB4BW333	PUSH BUTTON	MOMENTARY GREEN
B02-39-199	ZB4BL4	PUSH BUTTON	MOMENTARY RED
B02-39-203	ZB4BW143	PUSH BUTTON	MOMENTARY RED
B02-39-095	CBK-MPIFR	PUSH BUTTON	R ILLUMINATED
B02-39-020	52AAGP	PUSH BUTTON	RED
B02-39-052	9001KR3RH6	PUSH BUTTON	RED
B02-39-305	800EM-LE4	PUSH BUTTON	RED EXTENDED 22MM, ILLUMINATED
B02-39-193	XY2CH13150H7	PUSH BUTTON	STANDARD CABLE PULL SWITCH
B02-39-152	GSW-23	PUSH BUTTON	SWITCH RED, NC
B02-39-274	CBK-MPIFW	PUSH BUTTON	WHITE ILLUMINATED
B02-39-181	MP1-31L	PUSH BUTTON	ILLUM, FLUSH MOMENTARY, BLUE
B02-39-232	MP1-31G	PUSH BUTTON	ILLUM, FLUSH MOMENTARY, GREEN
B02-39-239	MP1-31W	PUSH BUTTON	ILLUMINATED, MOMENTARY, FLUSH, WHITE
B02-39-091	CBK-MPB	PUSH BUTTON	MR.BLACK
B02-39-092	CBK-MPG	PUSH BUTTON	MR.GREEN
B02-39-098	CBK-MPR	PUSH BUTTON	MR.RED
B02-39-014	3SB3500-OBA21	PUSH BUTTON	STOP RED
B02-39-030	800T-FXQ10BA	PUSH BUTTON	PUSH/PULL BUTTON
B02-39-031	800T-FXQ10GA	PUSH BUTTON	PUSH/PULL BUTTON
B02-39-294	800EM-LMP24	PUSH BUTTON	E-STOP PUSH-PULL BUTTON ILLUMINATED, 40MM

<b>SELECTOR</b>			
B02-39-086	CBK-M2BMKIG	SELECTOR	SEL 2 POS. ILL. GREEN
B02-39-087	CBK-M2BSLE	SELECTOR	SEL 2 POS. SPRING RETURN GREY LONG HANDLE
B02-39-085	CBK-M2AMK	SELECTOR	SELECTOR 2 POSITIONS BLACK.MAIN
B02-39-303	800EM-SM22	SELECTOR	SELECTOR 2 POSITIONS MAINTENED
B02-39-277	ZB4BD3	SELECTOR	SELECTOR 3 POSITIONS
B02-39-089	CBK-M3SK	SELECTOR	SELECTOR 3 POSITIONS
B02-39-090	CBK-M3SRK	SELECTOR	SELECTOR 3 POSITIONS
B02-39-210	CBK-S3KM4	SELECTOR	SELECTOR 3 POSITIONS
B02-39-088	CBK-M3MK	SELECTOR	SELECTOR 3 POSITIONS BLACK.MAINT
B02-39-054	9001KS11FB	SELECTOR	SELECTOR HEAD 2 POS.

# BUTTONS AND CONTACTS

B02-39-288	ZB5AG3	SELECTOR	HEAD SELECTOR WITH KEY
B02-39-289	ZB5AG0	SELECTOR	HEAD SELECTOR WITH KEY 3 POSITION
<b>SELECTOR SWITCH</b>			
B02-39-003	3223J	SELECTOR SWITCH	SELECTOR SWITCH
B02-39-033	800T-H2A	SELECTOR SWITCH	SELECTOR SWITCH
B02-39-246		SELECTOR SWITCH	SELECTOR SWITCH
B02-39-216	M2SSK2-101	SELECTOR SWITCH	SELECTOR SWITCH 2POS 22MM MAIN. KEY REMOVE IN B ONL
B02-39-215	M2SSK1-101	SELECTOR SWITCH	SELECTOR SWITCH 2POS 22MM MAIN. KEY REMOVE IN B/C
B02-39-255	M2SSK1-301	SELECTOR SWITCH	SELECTOR SWITCH 2POS 22MM MAINT. KEY, CHROME
B02-39-211	M2SS2-31G	SELECTOR SWITCH	SELECTOR SWITCH 2POS 22MM MAINT., A-C, GREEN ILL.
B02-39-245	M2SS1-31G	SELECTOR SWITCH	SELECTOR SWITCH 2POS 22MM MAINTAINED,BC, GREEN ILLUM
B02-39-213	M2SS2-30B	SELECTOR SWITCH	SELECTOR SWITCH 2POS 22MM MAINTAINED, A-C, BLACK
B02-39-217	M2SSK3-101	SELECTOR SWITCH	SELECTOR SWITCH 2POS 22MM MOM. KEY REMOVE IN B POS
B02-39-214	M2SS6-30U	SELECTOR SWITCH	SELECTOR SWITCH 2POS 22MM SPRING RETURN C-B, GREY
B02-39-254	M3SS2-31U	SELECTOR SWITCH	SELECTOR SWITCH 3 POS. GREY
B02-39-221	M3SS3-30B	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM
B02-39-218	M3SS1-30B	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM MAINTAINED, A-B-C, BLACK
B02-39-212	M2SS2-10B	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM MAINTAINED, A-C, BLACK
B02-39-253	M3SS2-31G	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM SPRING RET AB/CB, GREEN
B02-39-219	M3SS2-30B	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM SPRING RETURN AB/CB, BLACK
B02-39-275	M3SS2-30U	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM SPRING RETURN AB/CB, GREY
B02-39-220	M3SS3-30B	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM SPRING RETURN C-B, BLACK
B02-39-252	M2SS2-30U	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM SPRING RETURN C-B, GREY
B02-39-222	M3SSK3-101	SELECTOR SWITCH	SELECTOR SWITCH 3POS 22MM SPRING RETURN. KEY, BLACK
B02-39-061	CBK-2AMKE	SELECTOR SWITCH	SELECTOR SWITCH GREY 2 POSITION
B02-39-198	ZB4BK1233	SELECTOR SWITCH	SELECTOR SWITCH ILLUMIN. GREEN
B02-39-197	ZB4BD2	SELECTOR SWITCH	SELECTOR SWITCHES 2 POS MAINTAINED
B02-39-055	9001KS53B	SELECTOR SWITCH	SELECTOR SWITCHES 3 POS RETURN TO





# BUTTONS AND CONTACTS

			CENTER
B02-39-133	CBK-S3KS2	SELECTOR SWITCH	KEY SELECTOR.MOM. 3 POS.
B02-39-285	ZB4BG0	SELECTOR SWITCH	KEYED SELECTOR SWITCH 3 POSITONS
B02-39-313	XY2CE2A 170H7	SWITCH	E-STOP ROPE SWITCH 2NC FOR UP TO 50M ROPE

---

EMP DISTRIBUTION & SERVICE  
1930 A 52nd Avenue  
Lachine (QC) Canada  
H8T 2Y3

Tel: (514) 631-8771  
Toll-Free: 1-866-349-0959  
Fax: (514) 633-6798