



EMP Code	Product Code	Name	Description
----------	--------------	------	-------------

SPRING CLUTCH			
B01-08-011	306-17-051	CLUTCH	CB 6.CW.24 VDC.1 STOP.0.75 BORE
B01-08-012	306-17-053	CLUTCH	CB 6.CW.115 VAC.1. STOP 0.7
B01-08-013	306-27-039	CLUTCH	CB 6 CLUTCH WITH 1/2 ROT.,3/4"SHAFT
B01-08-075		CLUTCH	SUPER CB6-CCW 24VDC 1 STOP
B01-08-015	326-17-019	CLUTCH	SUPER CB6. CW. 115 VAC. 1 STOP (3/4 MIN BORE)
B01-08-069	326-27-019	CLUTCH	CLUTCH CB6 120VAC CCW
B01-08-014	308-17-107	CLUTCH	CB 8. CW. 115VAC. 1 STOP. 1.2
B01-08-081	300-12-033	CLUTCH	CLUTCH CB10 115 VA 1 1/2
B01-08-007	2004-0014	CLUTCH	CLUTCH (ADAM CLUTCH) 400SERIES PILOT MOUNT
B01-08-088	X5A2H-STH	CLUTCH BRAKE	CLUTCH BRAKE COMBINATION
B01-08-063	6011-448-001	CLUTCH	CBC-200 MANUAL CONTROL 115VAC IN / 0-90VDC OUT
B01-08-070	828900	CLUTCH	CLUTCH-BRAKE DIA 1" PILOT MOUNT

CLUTCH ACCESSORIES		
B01-08-001	101-0-0005	115ACW.E.COIL
B01-08-002	101-0-0073	COIL ASSEMBLY 24V DC
B01-08-048	101-1-0028	COIL ASSEMBLY 24V
B01-08-042	101-1-0053	COIL ASSY 24VDC
B01-08-043	101-1-0058	COIL ASSY 120V
B01-08-003	102-0-0008	ACTUATOR
B01-08-004	102-0-0009	ACTUATOR LEVER
B01-08-005	102-1-0032	ACT SUBASSY KIT CW AC/DC
B01-08-006	107-0-0001	ADJUSTER BRAKE SPRING FOR CB10

B01-08-040	266-0-0127	CB10 CONTROL COLLAR
B01-08-027	266-0-0321	CB10SP CONTROL COLLAR
B01-08-044	266-6-0750	CONTROL COLLAR
B01-08-036	266-8-0251	CB8 CONTROL COLLAR
B01-08-008	275-0-8021	COIL ASS:115V (CB10 SP)
B01-08-066	43	COMPRESSION SPRING # 43
B01-08-049	540-6-0001	BRAKE HUB
B01-08-047	540-6-0003	FLANGED HUB
B01-08-038	540-8-0014	FLANGED HUB
B01-08-037	540-8-0016	FLANGED HUB
B01-08-039	541-0-0002	INPUT HUB
B01-08-028	541-0-0028	CB10SP INPUT HUB
B01-08-029	541-0-0029	CB10SP BRAKE HUB
B01-08-046	541-6-0035	FLANGED HUB
B01-08-045	541-6-0045	BRAKE HUB
B01-08-057	661-1-0010	PIVOT PIN JAM NUT FOR CUT
B01-08-056	679-0-00004	ACTUATOR PIVOT PIN FOR CUTTER
B01-08-084	748-1-0217	SHIM
B01-08-083	807-0-0013	SHIM
B01-08-053	807-1-0014	SHIM
B01-08-082	807-1-0017	SHIM
B01-08-071	656-188	SHIM WASHER
B01-08-055	807-0-0012	WASHER
B01-08-052	807-1-0001	WASHER
B01-08-064	808-0-0003	DRIVE SPRING
B01-08-041	808-0-0007	ANTI-BACK SPRING
B01-08-031	808-0-0025	ANTI-BACK SPRING
B01-08-034	808-0-0026	ANTI-BACK SPRING
B01-08-022	808-6-0004	ANTI-BACK SPRING FOR CB6-CCW
B01-08-016	808-0-0004	ANTI-OVERUN SPRING LOADED
B01-08-023	808-6-0005	ANTI-OVERRUN SPRING FOR CB6
B01-08-024	808-6-0006	ANTI-OVER RUN SPRING FOR CB6 XXW
B01-08-030	808-0-0009	DRIVE SPRING
B01-08-017	808-0-0010	SPRING SET FOR CCW
B01-08-018	808-0-0021	BRAKE SPRING (CB10SP)
B01-08-019	808-0-0022	BRAKE SPRING
B01-08-020	808-6-0001	DRIVE SPRING (CB6)
B01-08-050	808-6-0002	DRIVE SPRING
B01-08-021	808-6-0003	SPRING: L.H. CW
B01-08-025	808-8-0003	DRIVE SPRING (CB8)
B01-08-033	824-0-0105	CB10SP OUTPUT ASSY

B01-08-051	824-6-0002	INPUT SHAFT 3/4
B01-08-086	824-6-0478	OUTPUT SHAFT SUPER 3/4
B01-08-035	824-8-0328	CB8 OUTPUT ASSY
B01-08-061	AW08	LOCK WASHER FOR SPECIAL BEARINGS 32009XJ
B01-08-060	BINDER BRAKE COIL	COIL 230V DELTA 6 LEADS 400V Y CONNECTION 3P 50HZ
B01-08-078	MO11883	DRIVE SPRING (CB10) RIGHT HAND
B01-08-077	MO11884	DRIVE SPRING (CB10) RIGHT HAND
B01-08-076	MO11885	DRIVE SPRING (CB10) RIGHT HAND
B01-08-079	MO11886	DRIVE SPRING (CB10) RIGHT HAND
B01-08-054	748-1-0036	RETAINING RING
B01-08-032	748-1-0039	RETAINING RING
B01-08-080	748-1-0045	RETAINING RING
B01-08-074	DH0-032PA	RETAINING RING 32MM INTERNAL
B01-08-073	DH0-035PA	RETAINING RING 35MM INTERNAL
B01-08-072	DH0-045PA	RETAINING RING 45MM INTERNAL
B01-08-068	DH0-22PA	RETAINING RING 22MM INTERNAL
B01-08-067	N1300-125 AS	RETAINING RING SS
B01-08-065	N1300-162	RETAINING RING
B01-08-059	N1400-137	RETAINING RING

CLUTCH MAGNETIC			
B01-08-026	C-10A	CLUTCH MAGNETIC PARTICLE	SERIES 10 WITH AIR FAN
B01-08-058	C-50A	CLUTCH MAGNETIC PARTICLE	SERIES 50 WITH AIR FAN
B01-08-062	MPC70-1-90	MAGNETIC CLUTCH	90VDC

PNEUMATIC CLUTCH			
B01-08-087	C4E2H-STH	PNEUMATIC CLUTCH	1317 LBS-IN
B01-08-085	C5D2R-STH	PNEUMATIC CLUTCH	2587 LBS-PO