

PARTS FOR EPP

EMP CODE	DESCRIPTION
B01-32-132	COVER FOR PUMP
B01-32-133	IMPELLER
B01-32-134	PAPER GASKET
B01-32-135	SCREW
B01-32-136	MECHANICAL SEAL
B01-32-137	RACK
B01-32-138	OIL SEAL
B02-27-222	SEAL RING FOR EEP 1500
B02-27-224	GASKET FOR EEP1500
B02-27-225	MECHANICAL SEAL FOR EEP1500
B02-27-226	RETAINING COLLAR FOR EPP1500
B02-27-227	OIL SEAL FOR EEP1500
B02-27-231	AIR-OUT SCREW (same as B02-27-232 and B01-32-070)
B02-27-232	WATER-IN SCREW (same as B02-27-231 and B01-32-070)
B02-27-233	SEEP-OUT SCRE FOR EEP1500